

ATTENZIONE!

CODICE

101050

Per le versioni Kube:

Il ricevitore è montato all'interno della centralina e non è munito di pulsanti (né fungo, né pulsante verde di ripristino, né spia segnalazione stato di emergenza).

Il ripristino dalla condizione di emergenza è possibile da trasmettitore nel seguente modo: premere e mantenere premuto per almeno 3 secondi consecutivi un pulsante funzione del trasmettitore, rilasciarlo per almeno 2 secondi consecutivi e a quel punto il ricevitore è ripristinato e pronto per ricevere nuovi comandi.

pag.1



O.M.F.B. S.p.A. Hydraulic Components
We reserve the right to make any changes without notice.
Edition 2012.11 No reproduction, however partial, is permitted.
Via Cave, 7/9 25050 Provaglio d'Iseo (Brescia) Italy Tel.: +39.030.9830611
Fax: +39.030.9839207-208 Internet:www.omfb.it e-mail:info@omfb.it

ATTENZIONE!

CODICE

101050

Per le versioni Kube:

Il ricevitore è montato all'interno della centralina e non è munito di pulsanti (né fungo, né pulsante verde di ripristino, né spia segnalazione stato di emergenza).

Il ripristino dalla condizione di emergenza è possibile da trasmettitore nel seguente modo: premere e mantenere premuto per almeno 3 secondi consecutivi un pulsante funzione del trasmettitore, rilasciarlo per almeno 2 secondi consecutivi e a quel punto il ricevitore è ripristinato e pronto per ricevere nuovi comandi.

pag.1



O.M.F.B. S.p.A. Hydraulic Components
We reserve the right to make any changes without notice.
Edition 2012.11 No reproduction, however partial, is permitted.
Via Cave, 7/9 25050 Provaglio d'Iseo (Brescia) Italy Tel.: +39.030.9830611
Fax: +39.030.9839207-208 Internet:www.omfb.it e-mail:info@omfb.it

ATTENTION!

CODE

101050**For KUBE versions:**

The receiver unit is fitted inside the power unit and it is not provided with any buttons or switches.

To restore the standard status it is possible to do it through the sender unit as follows: press any function switch of the sender unit and hold it for at least 3 seconds; release it for at least two seconds and after that the receiver unit is restored to the standard function and ready to operate.

pag.2



O.M.F.B. S.p.A. Hydraulic Components
We reserve the right to make any changes without notice.
Edition 2012.11 No reproduction, however partial, is permitted.
Via Cave, 7/9 25050 Provaglio d'Iseo (Brescia) Italy Tel.: +39.030.9830611
Fax: +39.030.9839207-208 Internet:www.omfb.it e-mail:info@omfb.it

ATTENTION!

CODE

101050**For KUBE versions:**

The receiver unit is fitted inside the power unit and it is not provided with any buttons or switches.

To restore the standard status it is possible to do it through the sender unit as follows: press any function switch of the sender unit and hold it for at least 3 seconds; release it for at least two seconds and after that the receiver unit is restored to the standard function and ready to operate.

pag.2



O.M.F.B. S.p.A. Hydraulic Components
We reserve the right to make any changes without notice.
Edition 2012.11 No reproduction, however partial, is permitted.
Via Cave, 7/9 25050 Provaglio d'Iseo (Brescia) Italy Tel.: +39.030.9830611
Fax: +39.030.9839207-208 Internet:www.omfb.it e-mail:info@omfb.it